

ZwickMaterials Testing



Product Information

Robotic Testing System 'roboTest A' (Compact)



Robotic testing system 'roboTest A' with testing machine 20 kN



Pincer gripper removes a specimen from the magazine

Applications

The robotic testing system is used for the fully automatic performance of tensile tests on:

- Metallic specimens
 (e.g. according to DIN EN 10002-1, ISO 6892, JIS Z 2201, ASTM E8)
- Plastics specimens (e.g. according to ISO527-2, ASTM D790)
- Dimensionally stable specimens of other materials (e.g. wood)

System Configuration

- Materials testing machine 5 kN up to 250 kN with symmetrically closing, pneumatic or hydraulic specimen grips and an optional extensometer
- Robotic feeding system 'roboTest A' with integrated magazine for 20 specimens
- Industry Controller with test software testXpert® and automation software autoEdition2

Advantages of the Robotic Testing System 'roboTest A'

- A high reproducibility of the test results is obtained because operator influences are excluded (hand temperature, moist hands, eccentric or inclined insertion of specimens etc.).
- Qualified laboratory staff is relieved of routine jobs and is thus available for more complex activities.
- The machine can be used during idle times (break, night shift) thus increasing the rate of utilization and allowing "quicker" results.
- The system reduces the testing costs per specimen and usually pays off within one to two years.
- Manual tests are still possible by simply pushing the robotic feeding system aside.
- The automatic data logging system ensures secure documentation and enables statistical long-term monitoring (Statistical Process Control).



ZwickMaterials Testing

Product Information

Robotic Testing System 'roboTest A' (Compact)



Working area of the robotic testing system 'roboTest A'

Test Sequence

- The user fills the specimen magazine directly on the robotic testing system. A refilling of specimens in magazine places that were not yet worked off is possible at any time.
- The specimen data (ident number, width, thickness,...) are entered on the PC. In barcode operation this step can be omitted.
- After the startup of the system on the PC, specimen feed, tensile test and removal of the specimen fragments are carried out automatically.

Technical Data

Swivellable at the load frame
20 specimens
1500 x 690 ¹⁾ / 840 ²⁾ x 600 mm
Approx. 85 kg
(without specimen)

¹⁾ Load frame in profile design

²⁾ Load frame in column design

Connected values	
Electrical connection	230/115 V
Output	200 VA
Mains frequency	50/60 Hz
Compressed air	6 bar
Required compressed air	2 lpm

Control	
Automation software	autoEdition2
Peripheral connection	PROFIBUS

Specimens	
Specimen type	dumbbells, stripes, tubes,
	round or profile specimens
 Material 	dimensionally stable
 Weight 	max. 300 g
Length	max. 300 mm
Width (flat)	max. 33 mm
Diameter (round)	max. 20 mm
• Thickness (incl. bending)	max. 20 mm

Options

- Specimen identification by barcode
- Data exchange with superior processor systems (e.g. LIMS) via upload/download of ASCII-files or ODBC
- Optical status indicator by threefold "traffic light" (running, refill specimens/finished, error)



成分分析仪器 | 表面测试仪器 | 样品前处理仪器

上海市闵行区春申路2525号芭洛商务大楼 电话:021-8039 4499 传真:021-5433 0867 上海|北京|沈阳|太原|长沙|广州|成都|香港 全国销售和售后服务电话:400-808-4598 邮编:201104 , China 邮箱:shanghai@uzong.cn

更多信息请访问:www.uzong.cn





了解我们

微信公众長