


ZwickMaterials Testing



Product Information

Robotic Testing System 'roboTest B' (Compact)



Robotic testing system 'roboTest B' with testing machine 20 kN



Pincer gripper removes a specimen from the magazine

Applications

The robotic testing system is used for the fully automatic performance of:

- Tensile tests on plastics specimens (e.g. according to ISO 527-2, ISO 3167, ASTM D638)
- Flexure tests on plastics specimens (e.g. according to ISO 178)
- Tensile or flexure tests on dimensionally stable specimens of other materials

System Configuration

- Materials testing machine 5 kN up to 100 kN with symmetrically closing, pneumatic or hydraulic specimen grips and an optional extensometer
- Robotic feeding system 'roboTest B' with integrated magazine for max. stacking height 80 mm (for typically 20 specimens)
- Industry Controller with test software testXpert® and automation software autoEdition2

Advantages of the Robotic Testing System 'roboTest B'


- A high reproducibility of the test results is obtained because operator influences are excluded (hand temperature, moist hands, eccentric or inclined insertion of specimens etc.).
- Qualified laboratory staff is relieved of routine jobs and is thus available for more complex activities.
- The machine can be used during idle times (break, night shift) thus increasing the rate of utilization and allowing "quicker" results.
- The system reduces the testing costs per specimen and usually pays off within one to two years.
- Manual tests are still possible by simply pushing the robotic feeding system aside.
- The automatic data logging system ensures secure documentation and enables statistical long-term monitoring (Statistical Process Control).



ZwickMaterials Testing

Product Information

Robotic Testing System 'roboTest B' (Compact)



Robotic testing system 'roboTest B'

Test Sequence

- The user fills the specimen magazine directly on the test system.
- The specimen data (ident number, width, thickness,...) are entered on the PC. In barcode operation this step can be omitted.
- After the startup of the system on the PC, specimen feed, tensile/bending test and removal of the specimen fragments are carried out automatically.

Technical Data

Mechanics	
Mounting	swivellable at the load frame
Capacity	20 specimens (thickness 4 mm)
Dimensions (H x W x D)	680 x 680 ¹⁾ / 840 ²⁾ x 930 mm
Weight	approx. 85 kg
	(without specimen)

¹⁾ Load frame in profile design

²⁾ Load frame in column design

Connected values	
Electrical connection	230/115 V
Output	200 VA
Mains frequency	50/60 Hz
Compressed air	6 bar
Required compressed air	2 lpm

Control	
Automation	autoEdition2
Peripheral connection	PROFIBUS

Specimens	
 Specimen type 	dumbbells, stripes
 Material 	dimensionally stable,
	non-adhesive
 Weight 	max. 100 g
Length	80 220 mm
Width	15 30 mm
 Thickness 	4 mm

Options

- Specimen identification by barcode
- Specimen remains sorting
- Data exchange with superior processor systems (e.g. LIMS) via upload/download of ASCII-files or ODBC
- Optical status indicator by threefold "traffic light" (running, refill specimens/finished, error)



成分分析仪器 | 表面测试仪器 | 样品前处理仪器

上海市闵行区春申路2525号芭洛商务大楼 电话:021-8039 4499 传真:021-5433 0867 上海|北京|沈阳|太原|长沙|广州|成都|香港 全国销售和售后服务电话:400-808-4598 邮编:201104 , China 邮箱:shanghai@uzong.cn

更多信息请访问:www.uzong.cn





了解我们

微信公众号