

# NANO-MASTER PECVD and PE-MOCVD SYSTEMS



**NPE-4000 with ICP Source  
(Selective Growth of CNT)**

## Description:

NPE-4000 PECVD system is capable of depositing high quality  $\text{SiO}_2$ ,  $\text{Si}_3\text{N}_4$ , or DLC films on up to 8" diameter substrate sizes. To generate plasma, it uses RF shower-head electrode or Hollow Cathode RF plasma source with Fractal Gas Distribution. It is a stand alone PC controlled system. The platen can be biased with RF or pulsed DC and it is heated resistively or cooled with chilled water circulation. The aluminum chamber is evacuated to low  $10^{-7}$  torr pressure using 200 l/sec. Turbomolecular pump backed with 3.5 cfm mechanical pump. Standard unit comes with one carrier gas and two reactive gas lines and with optional mass flow meters. NPE-4000 system is designed for most demanding applications in R&D environments. Its unique gas distribution system and the planar Hollow Cathode Plasma source makes it possible to meet wide range of requirements such as plasma density, uniformity, and separate activation of reactive species to cover broadest possible deposition parameters.

## Applications:

- $\text{SiO}_2$ ,  $\text{Si}_3\text{N}_4$ , DLC, other Film
- Selective Growth of CNT
- Plasma Induced Surface Modification
- Plasma Cleaning ( $\text{NF}_3$ )
- Plasma Polymerization

## Specifications:


- Stand alone PC controlled system
- RF shower head or HCD plasma source
- Up to 8" diameter substrates
- RF biased substrate holder
- Water cooled platen
- One carrier gas and two reactive gas input with mass flow controllers
- Turbomolecular pump
- Vacuum  $10^{-7}$  torr range base pressure
- Pneumatically controlled valves

## HCD P100 Plasma Source:

- 5" or 8" Multijet Planar Hollow Cathode source
- 600 watts water cooled RD operation
- Fractal monomer and carrier gas feed
- High density plasmas  $10^{13}$  ions/cc
- Excellent uniformity and low contamination



**8" Platen at 600 °C**




**8" Platen at 700 °C**




**300 W RF Bias**



**-1000 V DC Bias,  
500 °C, ICP On**



**-500 V Bias, 700 °C,  
ICP Off**



**700 °C, ICP On**

[sales@nanomaster-china.com](mailto:sales@nanomaster-china.com) | [www.nanomaster-china.com](http://www.nanomaster-china.com)




咨询电话: 021-31663529

上海:Rm. 0502 building 14, No. 728 Laohumin Rd, Xuhui District

香港:12/F., San Toi Building,137 -139 Connaught Road Central

美国:3019 Alvin Devane Blvd., Suite 300, Austin, Texas 78741

# NANO-MASTER PECVD and PE-MOCVD SYSTEMS



**NPE-3000 Table Top  
PECVD System**

## System Options:

- HCD Plasma Source 5" or 8"
- Electropolished stainless steel chamber
- Heated platen
- Door for wafer load unload with 5" window
- Load lock
- Adjustable height platen
- Corrosive pump package
- Additional gas lines
- Heated gas lines
- HMDS or heated liquid delivery system
- 1 kw RF source
- Pulsed DC power supply
- Langmuir probe

## General Specifications:

Platen size	8"
Source diameter	5" or 8"
Number of gas feeds	4 (2 reactive, 1 carrier, 1 vent)
Source to platen distance	2" (or adjustable)
Vacuum	Low $10^{-7}$ torr range, 200 l/sec turbo with 3.5 cfm mech.
Maximum platen temp.	400 °C
RF power supply source	600 W, 13.5 MHz
RF bias	300 W, 13.5 MHz

## Facilities Required:

Power	110 V, 40 Amp, 50/60 Hz
Chilled water	15 °C, 10 liters/min
Process gasses	Ar, N <sub>2</sub> , SiH <sub>4</sub> , NH <sub>3</sub> , CH <sub>4</sub> , NF <sub>3</sub> , HMDS, etc.
Exhaust	For mechanical pump
Dry air	100 psi



## **NMC-3000 PE-MOCVD System:**

- Five Bubblers
- Heated Gas Lines
- 950 °C Platen
- RF Plasma Source
- $5 \times 10^{-7}$  Torr Base Pressure