

CHEMIXX CMP

SEMI-AUTOMATIC WET PROCESSING SYSTEM

BENEFITS

- ÷ For 200 or 300mm wafers
- ÷ One scrubber module
- ÷ One electric media arm for 4 media lines
- ÷ Double side chuck
- ÷ BSR nozzle for DI-Water
- ÷ Controller unit via 10inch touch screen
- ÷ Integrated media supply system
- ÷ Manually operated & safety interlocked process chamber door
- ÷ Manual DI water gun
- ÷ Small footprint
- ÷ Designed for Institutes and R&D



*CHEMIXX CMP 30pm
semi-automated
wet processing system*

WET PROCESSING SYSTEM FOR
CLEANING CMP WAFERS

**HIGH-EFFICIENT
PARTICLE REMOVAL**

WAFERS UP TO 300MM

PROPERTIES

System for cleaning of
dry and wet wafers after CMP.

- ÷ Wafer sizes up to 300mm
 - 1x Mechanical cleaning (double-side);
scrubber module (brush made of PVA)
 - ÷ For DI-water, diluted ammonia and SC1 dispensing.
 - ÷ Double side cleaning chucks (4 or 8 inch);
with wheel drive assembly for low speed rotation (50-100 rpm)
 - 1x Chemical cleaning (top-side); media arm
 - ÷ Electric media arm for 4 lines/nozzles.
 - ÷ Puddle nozzles for DI-Water and diluted ammonia dispensing
 - ÷ Optional; Heated media lines up to 60°C (85°C depending on media)
 - ÷ BSR (Back Side Rinse) nozzle for DI-Water
 - ÷ Manually operated & safety interlocked process chamber door
 - ÷ Process chamber cover with flow holes.
 - ÷ Three integrated media supply systems for three different chemicals.
 - ÷ Manual DI-water gun outside of the process chamber.
 - ÷ Signal lamp with four light sections for visualization of the system status
 - ÷ Emergency stop button at systems front
- Optional; external media supply cabinet with 10 or 20 ltr. canister.

CONTROL UNIT (uiS)

UNIXX-Software (uiS) Osiris user interface

- ÷ 10" color touch screen as user terminal
- ÷ Language: German, English, French or Spanish
- ÷ Recipe editor to write, manage and system configure.
- ÷ Recipe storage function on flash drive or memory stick.
- ÷ Library function for recipes, flows, log file
(e.g. error tracking history)
- ÷ User management with password-protected service access.
- ÷ Update & backup function via USB or intranet connection



**INTEGRATED
WAFER
ROTATION
SYSTEMS**



PROCESS STATION FOR CMP WAFERS

- ÷ Multi-level process chamber with vertical movable concentric inner ring.
- ÷ Two separate motor drive units with servo motors for chuck rotation and for wafer support wheels rotation.



Scrubber module

- ÷ Double side wafer cleaning (pre- & final-cleaning)
- ÷ Simultaneous cleaning of top- and backside
- ÷ Oscillating movement of brushes
- ÷ Dispensing suitable with DI-water, diluted ammonia or SC1
- ÷ Automatic rinsing of the brushes from the spray bar
- ÷ Programmable pressure control
- ÷ Brushes made of PVA

TECHNICAL DATA (CHEMIXX CMP 30pm)

GENERAL

Wafer Size:	Ø200 mm (Ø8 inch) or Ø300 mm (Ø12 inch)
Motor speed:	up to 3.000 rpm, programmable in 1 rpm steps*
Step time:	1 up to 999,9sec, programmable in 0.1 sec steps
System frame:	made of powder-coated stainless steel
System housing:	made of PP white (optional FM 4910) and 4 adjustable feets
Process bowl:	made of PP natural
Process chamber:	made of PP white (optional PVDF)


**depending on chuck design, substrate weight and load*

REQUIREMENTS

Voltage:	400(208) VAC / 3 Phase / N / PE / 50(60) Hz
CDA:	8 bar, tube OD Ø10 mm
Vacuum:	-0.8 bar / -600 Torr, tube OD Ø10 mm
DI-Water:	4 bar, OD Ø16.7 mm (3/8")
Nitrogen (optional):	4.5 bar, PFA tube OD Ø10 mm
Drain:	Gravity OD Ø38mm
Exhaust-process:	1x OD Ø110mm, 50-180 m³/h

DIMENSIONS (WXDXH) approx.

Housing:	1200 x 650/850 x 1300/1900 mm (47.2 x 25.6/33.5 x 51.2/74.8 inch)
Height (lid open):	2000 mm (78.7 inch)



CHEMIXX CMP 30PM 200/300MM

The CHEMIXX CMP 30pm was designed as a stand-alone system with a small footprint it is ideal for limited space.

It provides a process station including one scrubber module and one electric media arm up to 4 media lines/nozzles. A specially developed chuck allows simultaneous cleaning of the wafer from above and below.

A BSR nozzle for DI water completes the cleaning process so that together with the scrubber module and a diluted ammonia nozzle, most of the particles can be removed.

The system has an easy-to-use interface with all the necessary functions, such as recipe programming, service, maintenance and user management.



LOCATIONS

GERMANY

Osiris International GmbH
Josef-Schüttler-Str. 2
78224 Singen Htw. | Germany

🏠 +49 7731 16 995 0
✉ info@osiris-nano.eu
🌐 www.osiris-nano.eu

Osiris International GmbH
Köpenicker Str. 325 | Haus 3
12555 Berlin | Germany

🏠 +49 30 25 55 904 0
✉ info@osiris-nano.com
🌐 www.osiris-nano.com

USA

Osiris International Inc.
Cave Creek AZ 85331
United States

🏠 (602) 524 9731
✉ info@osiris-nano.com
🌐 www.osiris-nano.com

Version: CHEMIXX CMP 30pm-datasheet-osiris-210830

Data, design and specification of custom built machines depend on individual process conditions and can vary according to equipment configurations. Not all specifications may be valid simultaneously. Illustrations in this brochure are not legally binding. Osiris International GmbH reserves the right to change machine specifications without prior notice.