



Thermography Using VarioCAM® hr

Building inspections using different detector formats



Img. 1: Standard mode with of (320 x 240) pixel detector resulting in 76.800 infrared pixels

Img. 2: Digitally zoomed into image 1 - Measurement error resulting from low geometrical resolution



Img. 3: Resolution Enhancement mode of (640 x 480) pixel detector resulting in (1.280 x 960) = 1.228.infrared pixels

Img. 4: Digitally zoomed into image 3 - Correct temperature measurement resulting in higher geometrical resolution